AM251522

SHOWER HANDSET



EASY TO CLEAN

This shower handset features rub clean nozzles which are easy to unblock helping to keep limescale build up to a minimum. To clean, simply rub the surface of the shower handset gently in a clockwise direction with your thumb to break away any hard water deposits which could affect the showers performace.

EASY TO INSTALL

- 1. Unscrew your exsisting shower handset from the shower hose and discard along with the old washer.
- 2. Clean the threads on the shower hose.
- 3. Position the washers supplied in the connectors on your shower hose and attach it to your shower handset. Do not over-tighten, finger tight only.
- 4. To retain the best quality finish, clean product regularly with a soft damp cloth. Do not use abrasive or chemical cleaners, as these may damage the product.

GENERAL SAFETY ADVICE

- For safety and convenience do not use with water above 65°C or with excessively high water pressure (max 50psi/3.5 bar.)
- To avoid the risk of scalding you should always check the water temperature before entering the shower.
- Always take care when using hot water, especially with children and NEVER leave a child unattended in the bathroom.



